

Slim Cool Keyboard

The Slim Cool is a 12-inch wide waterproof and contaminant proof keyboard with tactile feedback keys. The sealed and rigid surface is ideal for industrial, marine, and medical use, as well as other applications where moisture, cleaning, and durability are a consideration. Because the Slim Cool is also quieter than "standard" keyboards, they are great for applications where noise generated from "key-clicks" is a problem. The Slim Cool is compatible with standard keyboard layouts and drivers are not needed.

Weight:

590.0 g (1.3 lb.)

Dimensions:

295.0 mm x 140.0 mm x 15.0 mm

11.6" x 5.5" x 0.6"

Cable length:

1.83 m (6')

Storage temperature:

-20 °C - 70 °C

-4 °F - 158 °F

Operating temperature:

0 °C - 70 °C

32 °F - 158 °F

Voltage:

5 Volt

Current input:

26 mA

Composition:

100% Silicone Rubber

PVC Cable

100% Latex free

System requirements:

USB interface

PS/2 interface

(USB to PS/2 Adapter Not Included)

Number of keys:

86 US Layout keys. This keyboard

does not have a keypad.

Warranty period:

Limited lifetime warranty

*Specifications subject to change
without notice*

Installing Your Slim Cool Keyboard

USB: Attach the keyboard cable to a USB computer port. (You do not have to turn off your computer. There is no software to install.)

PS2: Turn off your computer before attaching devices. If you have another keyboard attached, disconnect it. Attach the PS2 keyboard Adapter (sold separately) to USB cable connector. Attach cable to the keyboard port. Turn on your computer to activate the keyboard. (There is no software to

Cleaning Instructions for Waterproof Keyboards and Mice:

1. Clean the surface of the product by wiping, brushing, spraying or dipping it. Use only rags, sponges or soft bristle brushes. **DO NOT place the USB or PS/2 connector into the fluid.**
2. Either wipe with dry cloth or allow to air dry.

Disinfectants recommended

- Chlorine based (max 10% solution) - Chlorox, Novatsan, etc.
- Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based - Cavicide, Isopropyl Alcohol, Medicide, etc.
- Oxidizing - Hydrogen Peroxide 3% Solution, Lifegard Series, etc.
- Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, etc.
- Soap and water

DO NOT USE:

- Petroleum based cleaning fluids, such as Gasoline
- Acetone
- Over 10% bleach solutions
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT.

THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE