

Cleaning Instructions & Recommended Disinfectants Silicone Rubber keyboard and/or mouse

Cleaning instructions:



1. If your keyboard has this special Locking Key symbol:
you can clean your keyboard while its plugged in; lock the keyboard by pressing the Locking Key for 3 seconds.
No locking Key? Unplug your keyboard before cleaning.
2. Clean the surface of the product by wiping, brushing, spraying (or by dipping: only with IP68 protection rating!). Use only rags, sponges or soft bristle brushes.
DO NOT place the USB (or PS/2) connector in the fluid!
3. Either wipe with dry cloth or allow to air dry.
4. Unlock the keyboard by pressing the Locking Key for 3 seconds, or re plug your keyboard.

Recommended Disinfectants:

- **Chlorine based (max 10% solution)** – Chlorox, Novalsan, etc.
- **Formaldehyde based** – Formaldehyde Solution 37%, Vinco Formaldegen...
- **Glutaddehyde based** – Aldacide 200, Lysofume, Wavicide, etc.
- **Phenol based** – Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- **Alcohol based** – Cavicide, Isopropyl Alcohol, Medicide, etc.
- **Oxidizing** – Hydrogen Peroxide 3% Solution, Lifegard Series, etc.
- **Quaternary Ammonium** – Roccal-D, Bacto-Sep, Parvosol, etc.
- **Soap and water.**
- **DO NOT USE:** Petroleum based cleaning fluids, such as Gasoline, Acetone, over 10% bleach solutions, temperature or pressure sterilization, buffing pads or scrubbing pads, high pressure cleaning.